




Without **ModuLite®** or **ModuLite® HD** all the additional power required to supply the trailer lights (represented by the red line) pass through the vehicle's electrical system including the fuse panel, turn signal switch, taillight harness and lamp out sensor if so equipped.



With **ModuLite®** all the additional power required to supply the trailer lights (represented by the green line) is supplied directly from the battery. Only a small amount of power is required from the fuse panel, turn signal switch, taillight harness and lamp out sensor if so equipped, to signal when to illuminate the trailer lights.

